

*(kit contents continue on following page)*

**Read instructions and view illustrations before beginning.**

**Need help with your installation?**



sales@superatv.com



www.superatv.com



1-812-574-7777



8:00am - 9:00pm EST M-Th  
8:00am - 7:00pm EST Friday  
9:00am - 2:00pm EST Saturday

*Thank You  
For Choosing*

**SUPERATV**.COM

**Liability Statement**

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.


Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.

17x  M6-1.0 Nylock Nut


(kit contents continued)

7x  M6 Flat Washer

7x  
  
Grommet

Clamp  7x

17x  M6-1.0 x 20mm Lg. BHCS

 Flat Seal


 Gasket

**Cleaning:**



- Do not use a dry cloth, or your hands, to wipe off surface; Scratching will occur.
  - Do not use window cleaning fluids (Windex, 409, etc) or any solvents (gasoline, denatured alcohol, acetone, etc).
  - Never use abrasive cleaners, abrasive pads, or gritty cloths.
1. Thoroughly rinse surface to float off dirt and mud.
  2. Using a soft cloth, or microfiber cloth, clean surface with warm water and a gentle detergent. Baby shampoo or hand washing soap are recommended.
  3. To prevent water spots, use a chamois and blot surface dry.



- Install Grommets into Roof (Front and Rear). To ease installation, apply soapy water to Rubber Grommets before inserting.



- Install Front and Rear Roof pieces to Bracket with M6-1.0 x 20mm Lg. PHMS and M6-1.0 Nylock Nuts.
- Flat Seal will install between Bracket and Roof pieces.



- Install Gasket and Clamps to Roll Cage as shown.



- Place Roof onto machine and secure to Clamps with hardware shown.
- Align to machine and tighten hardware completely.

