

INSTALLATION INSTRUCTIONS

Polaris RZR 3" Lift Kit

Item	Description	Qty
A	Spacers	4
B	M10-1.5 x 60mm Lg. HHCS	6
C	M10-1.5 Nylock Nuts	6
D	M10 Flat Washers	12
E	Front, Left Bracket (Inner)	1
F	Front, Left Bracket (Outer*)	1
G	Front, Right Bracket (Inner)	1
H	Front, Right Bracket (Outer*)	1
J	Rear, Left Bracket (Inner)	1
K	Rear, Left Bracket (Outer*)	1
L	Rear, Right Bracket (Inner)	1
M	Rear, Right Bracket (Outer*)	1

*Outer Brackets are TALLER than Inner Brackets

Installation Tools

17mm Socket/Wrench



Use Notches and Bevels to help orientation



Before installing, arrange Brackets as shown

Use Notches and Bevels to help orientation



This product is designed, and manufactured, to gain additional ground clearance on utility vehicles and to be used at slower speeds on level terrains. Installation of this product increases angle of Axles which may result in frequency of required maintenance and parts wear. It is recommend that wider Tires or Wheel Spacers be used, in conjunction, with this kit to improve stability.

Read instructions and view illustrations before beginning.

Need help with your installation?



sales@superatv.com



www.superatv.com



1-812-574-7777



8:00am - 9:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Thank You
For Choosing

Liability Statement

SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.

Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warranted if item was not installed properly, misused, or modified.

Do not tighten hardware completely unless noted.

Installation performed on a bare frame for clarity.

1. Raise machine off ground and secure on jack stands. Remove Wheels.
2. Unbolt Shocks from Lower A-Arms.
3. Loosen Nuts securing Front Sway Bar End Links.

FRONT

1. Install Front, Right Brackets (G)(H) and Spacer (A) as shown in Fig. 1. Secure using M10-1.5 x 60mm Lg. HHCS (A), M10 Flat Washers (D), and M10-1.5 Nylock Nut (C). See Fig. 1 and Fig. 1a.
2. Connect Shock and Sway Bar End Link to new brackets using stock hardware.
3. Tighten all hardware completely and repeat steps for opposite side.

REAR

1. Install Rear, Left Brackets (K)(J) and Spacer (A) as shown in Fig. 2. Secure using M10-1.5 x 60mm Lg. HHCS (A), M10 Flat Washers (D), and M10-1.5 Nylock Nut (C). See Fig. 2 and Fig. 2a.
2. Connect Shock to new brackets using M10-1.5 x 60mm Lg. HHCS (A), M10 Flat Washers (D), and M10-1.5 Nylock Nut (C).
3. Tighten all hardware completely and repeat steps for opposite side.

PARTS REFERENCE

Item	Description
A	Spacers
B	M10-1.5 x 60mm Lg. HHCS
C	M10-1.5 Nylock Nuts
D	M10 Flat Washers
E	Front, Left Bracket (Inner)
F	Front, Left Bracket (Outer*)
G	Front, Right Bracket (Inner)
H	Front, Right Bracket (Outer*)
J	Rear, Left Bracket (Inner)
K	Rear, Left Bracket (Outer*)
L	Rear, Right Bracket (Inner)
M	Rear, Right Bracket (Outer*)

