


INSTALLATION INSTRUCTIONS

Can-Am Commander Front Brush Guard



Item	Description
A	Front Brush Guard
B	Hoop
C	Mounting Bracket, Right
D	Mounting Bracket, Left

Read instructions and view illustrations before beginning.

Need help with your installation?



sales@superatv.com



www.superatv.com



1-812-574-7777



8:00am - 9:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

*Thank You
For Choosing*

SUPERATV.COM

(kit contents continue on following page)

Liability Statement



SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.

Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warranted if item was not installed properly, misused, or modified.

(kit contents continued)




SuperATV, WL-F LED Round Lights (not included) shown mounted using available locations in Front Brush Guard.




Do not tighten hardware completely unless noted.

1. If applicable remove stock Bumper.
2. Insert 9mm Thick Spacers into locations shown in Fig.1.
3. Install Mounting Brackets (C)(D) to machine using M8-1.25 x 25mm Lg. FHCS. See Fig. 2.
4. Install Hoop (B) to Front Brush Guard (A) with M8-1.25 x 20mm Lg. Carriage Bolts, M8 Flat Washers, and M8-1.25 Nylock Nuts. Tighten hardware completely. See Fig. 3.
5. Install Front Brush Guard (A) to Mounting Brackets (C)(D) using M8-1.25 x 20mm Lg. Carriage Bolts, M8 Flat Washers, and M8-1.25 Nylock Nuts. See Figs. 4 - 4a.
6. Align to machine and tighten all hardware.




(illustrations continue on following pages)

Fig. 3




Qty (4)



M8 x 20mm Lg.
Carriage Bolt

Qty (4)




M8 Flat Washer

Qty (4)



M8 Nylock Nut



- Qty (4)
M8 x 20mm Lg. Carriage Bolt
- Qty (4)
M8 Flat Washer
- Qty (4)
M8 Nylock Nut

