


INSTALLATION INSTRUCTIONS
Lift Kit: for Can-Am Outlander "L"

Item	Description	Item	Description
A	Front Bracket (left)	D	Rear Bracket (left)
B	Front Bracket (right)	E	Rear Bracket (right)
C	Rear Bracket		



Read instructions and view illustrations before beginning.

Need help with your installation?

sales@superatv.com
www.superatv.com

1-812-574-7777
 8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday

Thank You
For Choosing
SUPERATV.COM[®]

Liability Statement
 SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.


Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.


SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.

Front removal: *Keep all components removed from machine.*

- Raise front of machine and secure with jack stands. Remove Wheels, Shocks and hardware shown.




Front Assembly Reference (do not assemble at this time)




Front installation: *Do not tighten hardware completely unless noted.*

- Install Front Brackets left/right (A)(B) to Frame with hardware shown. Install 27mm Spacers at this time.



Front installation continued: *Do not tighten hardware completely unless noted.*


- Install Shocks to Front Brackets (A)(B) with hardware shown. Use stock hardware when securing Shocks to A-Arms.



Tighten all hardware completely.



Rear removal: *Keep all components removed from machine.*

- Raise rear of machine and secure with jack stands. Remove Wheels and Shocks.



Rear: Do not tighten hardware completely unless noted.

- Install Rear Bracket (C) to Frame with Bolts shown. Install 27mm and 32mm Spacers at this time. **DO NOT ADD NUTS.**
- Install Rear Brackets left/right (D)(E) onto previously installed Bolts and secure with Nuts shown.
- Install Shocks with stock hardware.



Tighten all hardware completely.