





740B Clifty Drive • Madison, Indiana 47250 • 812-574-7777

AAP4, Polaris Sportsman Offset A-Arms, Installation Instructions

Do not contact store where purchase was made. Dial 812-574-7777 for assistance.

Do not tighten hardware completely unless noted.

1. Raise Front of machine off ground, secure with jack stands, and remove Wheels.
2. Remove (2) Bolts securing A-Arm to Frame and pull A-Arm away from Frame. See Fig. 1 and Fig. 1a.
3. Remove Cotter Pin and Nut that secure Strut to A-Arm. To remove A-Arm from Strut, hit A-Arm with a rubber mallet. See Fig. 2.
4. Transfer stock Bushings into new A-Arm.
5. Install new A-Arm to Strut and Frame with stock hardware.
6. Repeat steps for opposite side.
7. Tighten all hardware securely and reinstall Wheels.



TROUBLESHOOTING:

If you have questions during installation of this product, please visit www.superATV.com. Latest version of these instructions can be found at same location. Free Technical Support is available by calling 812-574-7777.

Thank You
For Choosing
SUPERATV.COM

Liability Statement

SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.

Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warrantied if item was not installed properly, misused, or modified.