


Item	Description	Qty
A	Front Bracket (1)	1
B	Front Bracket (2)	1
E	Front Mounting Spacers	2
-	Rhino Brand Rear Axles	2



(Kit contents continue on following page)

Read instructions and view illustrations before beginning.

Need help with your installation?



sales@superatv.com



www.superatv.com



1-812-574-7777



8:00am - 9:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Thank You
For Choosing



Liability Statement

SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.


Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.


SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warranted if item was not installed properly, misused, or modified.

(Kit contents continued)

Item	Description	Qty
C	Rear Brackets (1)	2
D	Rear Brackets (2)	2
F	Rear Clamping Blocks	2




(Passenger)




(Passenger)

C



(Driver)

D









F

(Driver)

(Kit contents continue on following page)

(Kit contents continued)

Item	Description	Qty	Item	Description	Qty
G	M12-1.75 x 60mm Lg. HHCS	2	N	M8-1.25 x 25mm Lg. HHCS	4
H	Spacers, Ø17mm O.D. x 30mm Lg.	2	P	M8-1.25 x 55mm Lg. HHCS	4
J	M10-1.5 Nylock Nuts	4	Q	M8-1.25 Nylock Nuts	8
K	M10-1.5 x 60mm Lg. HHCS	4	R	Spacers, 9mm Thick	2
L	M12-1.75 Nylock Nuts	2	S	Spacers, Ø17mm O.D. x 25.5mm Lg.	2
M	Self Tapping Bolts	2	T	M8 Flat Washers	4





Do not tighten hardware completely unless noted. Keep all stock hardware removed from machine

FRONT

1. Raise front of machine off ground, secure with jack stands, and remove Wheels. Unbolt Shocks, and hardware shown in Fig. 1, from Frame. Disconnect Wire Harness from Frame and Differential Vent Tube.
2. Install Front Mounting Spacer (E) to Frame. Secure with stock hardware. See Figs. 2 - 2a.
3. Install Front Brackets (A)(B) to machine and secure with (4) each M10-1.5 x 60mm Lg. HHCS (K), M10-1.5 Nylock Nuts (J), and (2) Spacers, (H). See Figs. 2 - 2a.
4. Reinstall Shocks with stock hardware. See Fig. 3.
5. Tighten hardware completely, reroute and reconnect Differential Vent Tube, and reinstall Wheels.



REAR

1. Raise rear of machine off ground and secure with jack stands. Loosen Sway Bar hardware and remove Wheels, Spindels, and Axles. Remove Shocks and hardware from Frame. See Figs. 4 - 4a.
2. Install Rear Brackets (C)(D) to machine and secure with (1) each M12-1.75 x 60mm Lg. HHCS (G), M12-1.75 Nylock Nut (L), and Spacer (S). See Fig. 5.
3. Secure Rear Bracket (C) to machine using (1) Self Tapping Bolt (M) and Spacer (R). See Fig. 6.
4. Reinstall Shock with stock hardware. See Fig. 6.
5. Secure Rear Bracket (D) to Rear Bracket (C) with (2) each M8-1.25 x 25mm Lg. HHCS (N), M8 Flat Washers (T), and M8-1.25 Nylock Nuts (Q). See Fig. 6.
6. Install Rear Clamping Block (F) using (2) each M8-1.25 x 60mm Lg. HHCS (P) and M8-1.25 Nylock Nuts (Q). See Fig. 6.
7. Install new Axles.
8. Repeat steps for opposite side. See Fig. 7.
9. Tighten all hardware completely and reinstall necessary components.



(illustrations continue on following page)

(illustrations continued)





PARTS REFERENCE

Item	Description
A	Front Bracket (1)
B	Front Bracket (2)
E	Front Mounting Spacers
H	Spacers, Ø17mm O.D. x 30mm Lg.
J	M10-1.5 Nylock Nuts
K	M10-1.5 x 60mm Lg. HHCS
Q	M8-1.25 Nylock Nuts

(illustrations continue on following page)


(illustrations continued)



Item	Description	Item	Description
C	Rear Brackets (1)	N	M8-1.25 x 25mm Lg. HHCS
D	Rear Brackets (2)	P	M8-1.25 x 55mm Lg. HHCS
F	Rear Clamping Blocks	Q	M8-1.25 Nylock Nuts
G	M12-1.75 x 60mm Lg. HHCS	R	Spacers, 9mm Thick
J	M10-1.5 Nylock Nuts	S	Spacers, Ø17mm O.D. x 25.5mm Lg.
L	M12-1.75 Nylock Nuts	T	M8 Flat Washers
M	Self Tapping Bolts		

(illustrations continued)

Fig. 5



PARTS REFERENCE

Item	Description
C	Rear Brackets (1)
D	Rear Brackets (2)
F	Rear Clamping Blocks
G	M12-1.75 x 60mm Lg. HHCS
J	M10-1.5 Nylock Nuts
L	M12-1.75 Nylock Nuts
M	Self Tapping Bolts
N	M8-1.25 x 25mm Lg. HHCS
P	M8-1.25 x 55mm Lg. HHCS
Q	M8-1.25 Nylock Nuts
R	Spacers, 9mm Thick
S	Spacers, Ø17mm O.D. x 25.5mm Lg.
T	M8 Flat Washers

